





CLASS TONDA 330	DESCRIPTION	COL	CODE		Q.TY
	Driver 500mA		LB1070092		x1
	Board 3K		RC580007		x1
	Board 4K		RC580008		x1
	Diff. Opal		RC5800079		x1
	Diff. Semitrasp.		RC5800080		x1
	Anello bianco / Ring / Anneau / Anillo		RC580005		x1
			RC580006		x1
			RC580004		x1
	Driver + emergency kit		LB1070077		x1

CLASS TONDA 260	DESCRIPTION	COL	CODE		Q.TY
	Driver 500mA		LB1070092		x1
	Board 3K		RC590002		x1
	Board 4K		RC590003		x1
	Diff. Opal		RC590004		x1
	Diff. Semitrasp.		RC590005		x1
	Anello bianco / Ring / Anneau / Anillo		RC580002		x1
			RC580003		x1
			RC580001		x1
	Driver + emergency kit		LB1070077		x1

NOVA TONDA 330	DESCRIPTION	COL	CODE		Q.TY
	Driver 500mA		LB1070092		x1
	Board 3K		RC580007		x1
	Board 4K		RC580008		x1
	Anello bianco / Ring / Anneau / Anillo		RC800001		x1
			RC810001		x1
			RC810003		x1
	Driver + emergency kit		LB1070077		x1

Fino ad esaurimento. / Until our stock lasts. / Jusqu'à épuisement de stock. / Hasta el agotamiento del stock.

NOVA TONDA 260	DESCRIPTION	COL	CODE		Q.TY
	Driver 500mA		LB1070092		x1
	Board 3K		RC590002		x1
	Board 4K		RC590003		x1
	Vetro / Glass / Verre / Cristal		LB80200		x1
	Anello bianco / Ring / Anneau / Anillo		RC800002		x1
			RC810002		x1
			RC590001		x1
	Driver + emergency kit		LB1070077		x1

Fino ad esaurimento. / Until our stock lasts. / Jusqu'à épuisement de stock. / Hasta el agotamiento del stock.